

L.L.Bean

HOME

casual furnishings

RANGELEY BED

Honey



Thank you for purchasing our Rangeley Bed. Assembly of this product requires a Phillips and Flat head screwdriver. **We have found it helpful to have a second person present in at least one step of the assembly.**

0X858/X859/X860070702

STEP 1

Read through these instructions thoroughly before beginning assembly. We have found this to be of great value when first assembling this product.

STEP 2

Remove all parts and hardware from packing material. Wooden pieces should be placed on a non abrasive surface (like the carton or carpet) to prevent damage to the finish.

STEP 3

Identify all parts using parts list at right.

PARTS

- A. SIDE RAIL (2)
- B. HEADBOARD
- C. FOOTBOARD
- D. LONG SUPPORT BAR (FULL AND QUEEN)
- E. SMALL WOODEN LEG (QUEEN)
- F. WEBBING SLAT SYSTEM

STEP 4

Identify and count hardware using diagram at right.

Assembly of this product requires A Phillips and flat head screwdriver. **We have found it helpful to have a second person present in at least one step of the assembly.**

HARDWARE:

- 4 1 ¼" FLUTED DOWELS
- 2 SCREWS
- 8 BOLTS
- 8 BARREL NUTS
- 8 WOOD BUTTONS



STEP 5

Locate the two side rails (A), the headboard (B), and the footboard (C).



Side Rails (A)



Headboard (B)



Footboard (C)

STEP 6

Stand them headboard upright

STEP 7

Locate the 8 bolts and barrel nuts. Insert the barrel nuts into the holes on the inside of the side rails. Turn the groove on the end of each barrel nut so that it is going the length of the rail.



Step 8

Line up the end of one rail (finished side out) with the pre-drilled holes in the headboard (finished side with wood button facing in toward rail). Insert a bolt through each hole so that it screws into the barrel nut in the rail. Using a Phillips head screwdriver tighten the bolt (the use of a flat head screwdriver to hold the barrel nut in the correct position is recommended).



Step 9

Place footboard end (wood button side in) at the foot of the bed. Repeat step #8 to attach.

NOTE: Full and Queen size Only - Leave bolts a little loose for step 10 and 11.

Twin size skip to step #12



Step 10

Full Size Only – Locate the long support bar with screws attached to either end. Attach to the frame by positioning the support bar so that the screws on either end are placed into the notch on the metal brackets found on the frame ends. Push down to lock into place. Tighten all bolts.



Step 11

Queen Size Only- Locate the long support bar with screws attached to either end, and the small wooden leg with the 2" wooden dowels attached. – Line up the wooden leg with the dowels attached with the pre-drilled holes in the center of the support bar. Tap into place. Line up the support bar so that the screws at either end are into the notch on the metal brackets found on the frame ends. Push down to lock. Tighten all bolts.



Step 12 ALL SIZES

Locate the 4 - 1 1/4" fluted dowels. Put one dowel into each of the pre-drilled holes located on the inside edges of the rails. Tap into place.

Unroll the webbed slat system into the frame. The dowels will hold the last slat on each into position. Using the screws provided, screw the middle slat onto the rails through the pre-drilled holes.

STEP 13

Tap wood buttons into place on outside of the headboard and footboard to cover the bolt holes.



CARE

Use a clean soft cloth to dust.



www.llbean.com

Product Support 1 800 341 4341
