

June 22, 2007

Subject: **Recall for Genuine Innovations Second Wind MTB and Wrench Force Two Shot**
Importance: **High**

Dear Genuine Innovations Customer,

With over 18 years as the leader in bicycle and motorcycle tire inflation, our primary concern is the safety of our products. In conjunction with the Consumer Product Safety Commission (CPSC) we are announcing a voluntary product recall for the following items:

- **Genuine Innovations Second Wind MTB:** Part Numbers - 2525, 2525-0, and 3519
- **Wrench Force Two Shot:** Part Numbers - 84995, 84995-1, and 80383

The unit can shatter while under pressure when inflating tires. This poses a risk of injuries, such as bruising, lacerations, and ringing in the ears.

The new upgraded Second Wind MTB and Two Shot head has a Safety Relief Feature that prevents the unit from exceeding safe pressure levels. All products that have shipped from Genuine Innovations since January 1, 2007, have most likely been upgraded with the Safety Relief Feature and are safe for sale and use.

How to Verify Recalled Units

1) To locate the Safety Relief Feature, look at the head on a Genuine Innovations Second Wind MTB or Wrench Force Two Shot with lever to the left side. You will find the Safety Relief Feature by looking just below the sticker, at the flat surface that is at a right angle coming toward you. On this surface, you will see a small 3/16" in (4.75 mm) hole.

- a. **HEAD WITH SAFETY RELIEF** - If you have the Safety Relief Feature, the device has already been upgraded and is safe for use. Units shipped in 2007 should have upgraded safety release.



- b. **DEFECTIVE HEAD** - If the Head on your Genuine Innovations Second Wind MTB or Wrench Force Two Shot does not have the Safety Relief Feature contact Genuine Innovations



If your product needs a replacement head:

1. Stop using your Second Wind MTB or Wrench Force Two Shot immediately.
2. Please complete the Return Instructions on the back of the Safety Recall Notification from L.L.Bean.
3. Place the pump head, along with the completed return form, in the enclosed shipping envelope and attach the pink mailing label.
4. Mail via US postal service.
5. When we receive the defective head, we will promptly send you a Repair kit that contains a replacement head that has been upgraded with the Safety Relief Feature.

Thank you for your cooperation on this important matter.

Genuine Innovations